



1) Initial installation of unit using jack and temporary support braces along with level, unit should be slightly raised above level position.

2) Mount Grip-Tite™ cleats in appropriate position as shown.

A) Put slotted washer pointed side up on stud end of cable followed by flat washer, lock washer and hex nut. Thread hex nut until flush with stud end. Pull cable tight centering slotted washer and tap firmly in place into lower platform making sure that hex nut is flush to stud end so as to not damage threaded stud end. Once slotted washer is securely in place thread hex nut 3/8 inch up stud end. Repeat same procedure with other cable stud ends.

B) Mount with outside fingers pointing upwards

C) Wrap cable through first end finger of Grip-Tite™ cleat pulling cable tight; then weave cable through remaining fingers of cleat and thread excess cable through holes on top of Grip-Tite™ cleat and secure any excess cable over 12 inches with fence staple at any convenient location.

3) Carefully place load on cable system to seat cables.

4) **WARNING!** - For upward adjustment never lift unit by tightening cable hex nut - always use jack and temporary braces to lift unit before adjusting hex nut.

Hole plugs provided for special mounting situations where recessed holes or rigid installation is used.

WARNING! always use proper tools and caution when installing window unit.